





Outer Plate

F1616











F16 5 (PRIOR NET)


HOWMON' DONAMON



84 212 51 NBNO JO FRONT 4.8 COMPARTMENT CONTROL LOWER FINGER SY 08 51 <u>83</u> 62 b.L 14: LOWER FINGER 18 UPPER FINGER FINGER UPPER FINGER BURNER TUBE **B**£17 BELT CONVEYOR UPPER CONVEYOR FAN RIGHT FRN LEFT 85 78 23 of L 18 96 1051 36

36





- 1. ACTUAL TEMPERATURE
- 2. SET POINT; THE TEMPERATURE OF THE OVEN
- 3. UNLOCK; RETAINS DISPLAY FOR GO SECOND OR UNTIL
  HIDDEN KEY IS PRESSED

## DIAGNOSTIC

- 1. FLASHS "PLC" FAFAIL SAFE CONDITION EXSTS
  - · FLASHES "RUN" WHILE OVEN IS RUNNING NORMALLY
  - · FLASHES "DONE" WHEN RUN IS COMPLETED
  - " FLASHES " SE" IF INTITIAL TEMPERATURE IS LOW
  - · FLASHES " OPEN" IF OVEN IS OPEN
  - . FLASHES "IC" IF THEOMOCOUPLE LEADS ARE REVERSED

## SERVICE MODE

- OF DESIRED TEMPERATURE
- · DEGREE IN OVEN, GITHER IN CORINF
- · DEFAULT DISPLAY
- · OVER TEMPERATURE

F169